


**Configuration Sheet For**  
**Datalogic Magellan 9300i Scanner Scale RS232 OPOS**  
**To Work with Existco Plant Control System**

**1. Restore Defaults**



RETURN TO FACTORY SETTINGS

**2. USB OPOS**

**3. Disable Small Barcodes only Read 2D Datamatrix Barcode**