

Configuration Sheet For

Datalogic PM9500 OPOS Mode

1. Set Default




Scan Barcode in Red Number Sequence

Restore Custom Default Configuration

(1)

2. Enable EAN 128



Enter/Exit Programming Mode

(2)



Optional Add-Ons = Enable GS1-128

(3)



(4)

Global AIM ID = Disable



(5)

Label ID Transmission = Disable



(6)

Enter/Exit Programming Mode

3. SET OPOS Mode USB-OEM



(7)

Select USB-OEM