

Configuration Sheet

For

Honeywell Granit 1911i OPOS Mode

1. Restore defaults

Standard Product Defaults

The following bar code resets all standard product default settings.



Standard Product Defaults

2. USB OPOS

USB HID

Scan the following code to program the scanner for USB HID bar code scanners.



PAP131.

USB HID Bar Code Scanner

3. No Terminator

Suffix

If you want a carriage return after the bar code, scan the **Add CR Suffix bar code**. To add a tab after the bar code, scan the **Add Tab Suffix bar code**. Otherwise, scan the **Remove Suffix bar code** to remove the suffixes.



Add CR Suffix



Add Tab Suffix



Remove Suffix

4. Trigger Or Presentation



Manual Trigger - Normal
(Default)



Presentation Mode