

# **Configuration Sheet For Zebra Motorola Symbol Zebra DS3578 To Work with Existco Plant Control System**

- 1. Scan barcode in cradle then pace unit in cradle and wait for beep (Binding)**
- 2. Restore Defaults**



**\*Restore Defaults**

- 3. USB OPOS**



**USB OPOS Handheld**