

# **Configuration Sheet For Motorola Symbol Zebra LI4278 OPOS To Work with Existco Plant Control System**

Scan this barcode by the scanner to configure it to OPOS Mode  
(Which is required for PCS V2 Operations)



USB OPOS HAND-HELD

If issues occurs other codes needs to be scanned.



**\*Restore Defaults**



**\*Cradle Host**



**\*Point-to-Point Mode  
(0)**



**USB OPOS Handheld**